



## REMOTE CONTROL

## ➤ About Your Remote Control


---

Your EATEL FiberEdge TV remote control is a universal remote control which allows you to control your FiberEdge STB as well as your TV, VCR, DVD, and audio component. Refer to the manual that you received with the remote to get instructions on how to program it to work with the various components. While remote control models may vary slightly, basic functionality is the same on all EATEL remotes.

To access the device you wish to use, press the appropriate mode button on your remote (TV, CBL, DVD, VCR, etc.), then use the other buttons to perform the necessary tasks. The remote will “remember” which device you are working with until you select a different device using the mode buttons.

For example, if you want to turn on and use the VCR, press the VCR button on the remote, then the power button, then use the remote to control the VCR. When you are finished using the VCR and want to watch TV, simply press the cable button on the remote (CBL). Remember to point the remote control directly at the STB if you are using it to control your FiberEdge Digital TV service.

See the remote control diagrams on the following pages for more information about your specific remote. If you need additional assistance programming your remote, refer to the manual that you received with it, or contact EATEL.



## DEVICE CONTROLS

- 1 Powers on or off
- 27 Mode buttons - select which device to control
- 28 Used for all programming sequences

## DVR CONTROLS

- 18 Displays live TV
- 19 Displays a list of recorded programs
- 20 Replays the previous few seconds of a program

## VIEWING AND BROWSING CONTROLS

- 2 Displays the FiberEdge Interactive Menu
- 3 Displays channel and program information
- 4 Selects and deselects screen item
- 5 Navigates through program guide
- 6 Exits settings, menus, and guides
- 7 Accesses additional options in menus or guides
- 8 Views favorite channels
- 9 Returns to last channel
- 11 Enters channel numbers and programming
- 12 Adjusts picture format (certain TVs)
- 21 Accesses premium channels or interactive services
- 22 Selects channel up or down
- 23 Adjusts volume
- 24 Moves through selections
- 25 Accesses the STB box settings/options
- 26 Displays the interactive program guide (IPG)

## DVR/DVD/VCR/VOD CONTROL

- 10 Control buttons for DVR/DVD/VCR/VOD

## PICTURE IN PICTURE (PIP) CONTROLS

- 13 Moves the location of the PIP window
- 14 Changes the channel in the PIP window
- 15 Selects the video source
- 16 Switches the content being viewed in the PIP window with the program being viewed on the Main screen
- 17 Opens or closes the PIP window